**Hammermill Wear Parts** 



Cast replacement wear parts with improved wear life. 250-807-7999 wearparts@unicast.ca UNICAST.CA

## **Crusher Rotor Assemblies**

Unicast hammermill crusher rotor assemblies are precision balanced and feature wear-resistant WR3 for longer wear life.

## UNICAST HAMMERMILL CRUSHER ROTOR ASSEMBLIES

One-piece cast disks in wear-resistant WR3 for longer wear life.

Crusher rotor assemblies are precision balanced to eliminate vibration, a cause of excess bearing damage.

Longer wear life for better bottom lines.

